


# COBALT® INTEGRATOR PACKAGE TO SPI



The **COBALT integrator package** includes digital scan head, electrical, software and the necessary hardware needed to go from the SPI G3 laser to marking minus the cabinet and mounting surfaces in one complete package. All you need is a SPI laser source, 110 or 220 volts and a start marking dry contact closure.

The **Digital Scan Head** comes standard with a 160FL lens (several optional lenses available), mounting tube for the SPI colimator w/ 6 way adjustment and software interface boards.

The **Electrical Panel** consists of the laser power supply, USB software interface board, LMT break out board to SPI SCSI Control Cable, Scan head power supply, 2 drive boards for stepper motors, completely wired together and ready to plug in. All components are mounted inside of a NEMA electrical enclosure.

The **LMT Laser Software** is one of the most versatile and yet user friendly software packages. You can load any Windows type font, circle text, multiple lines, serial numbering, datamatrix codes, bar codes, graphics, import several different types of file formats, customize the settings for different materials, create several types of shapes as well as much, **much** more.

Laser Marking Technologies, LLC  
[www.lasermarktech.com](http://www.lasermarktech.com)  
Toll Free 866.799.0199